



Acer Iconia B1-720 Battery Replacement

This guide will show you how to remove this devices battery.

Written By: Kervis Boston






TOOLS:


- [iFixit Opening Tools](#) (1)
-

Step 1 — Rear Case



- Insert a plastic opening tool into a gap near the charging port at the top of the device. Slide the tool in either direction along the device.

Step 2




- Slide the tool along until you have completely separated the rear cover.
- If needed, place the first tool in the gap created to hold this gap open and use a second tool to pry the remaining portion of the rear cover off.

Step 3




- Once all the sides have been separated, you should be able to simply lift the cover off of the device.

Step 4 — Battery





- Peel back plastic tape covering the battery connector

Step 5



- Use plastic opening tool to lift battery off of the back panel. The adhesive used is strong so apply force during removal.

Step 6



- Lift battery off of panel gently. This will disconnect the battery connector from the motherboard.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-22 11:20:04 AM.